Function : Hour, Minute, Second & Date

PRESENTATION

Display Elements

Minute Hand
Hour Hand
Second Hand
Day
Date

Control Buttons

Crown Positions:

1. Normal position

2. Correction of Date

3. Correction hour, minute, day

SETTINGS

Setting the Time

1.1 Pull the crown to position 3.

1.2 Turn the crown clockwise to set the time (Check that AM / PM is set correctly).

1.3 Push the crown back in position 1.

1.1　　　　1.2　　　　1.3

Setting the Day

2.1 Pull the crown to position 3.

2.2 Turn the crown counter clockwise to set the day.

2.3 Push the crown back to position 1.

Please note:
In case of bilingual day calender, choose the desited language. When the day shifts automatically to the next day, the other language will appear temporarily.

2.1　　　　2.2　　　　2.3

Setting the Date

3.1 Pull the crown to position 2.

3.2 Turn the crown clockwise to set the date.

3.3 Turn the crown until the required date appears.

3.4 Push the crown back to position 1.

Please note:
The date will change gradully between 9:00pm and 4:00am. Therfore, do not set the date during this time period or the date may not change properly.
If it is necessary to set the calendar during that time period, first change the time to any time outside it, set the date and tien reset the correct time.

3.1　　　　3.2　　　　3.3