


Function : Hour, Minute & Second

PRESENTATION

Display Elements

Minute Hand
Hour Hand
24 Hours Hand
Second Hand



Control Buttons

Crown
1. Normal position
2. Setting of hour, minute

INSTRUCTIONS MANUAL Cal.82S7

SETTINGS

Setting the Time

- 1.1 Pull the crown to position 2.
- 1.2 Turn the crown to set hour and minute hands.
- 1.3 After the time has been set, push the crown back to position 1.

*24 Hour hand moves linked with the center Hour and Minute hand.



INFO

Winding the Mainspring

- Automatic winding watch can also be hand wound by turning the crown clockwise in position 1.
- Wind several times clockwise and it will start to move naturally.