


Function : Hour, Minute, Second & Date

PRESENTATION

Display Elements

Minute Hand
Hour Hand
Second Hand
Day
Date



Control Buttons

Crown Positions:
1. Normal position
2. Quick correction of day / date
3. Correction of hour, minute, day

INSTRUCTIONS MANUAL Cal.507/517

SETTINGS

Setting the Time

- 1.1 Pull the crown to position 3.
- 1.2 Turn the crown clockwise to set hour/minute hands to the desired time.
- 1.3 Push the crown back to position 1.

Please note:
70% of power is saved when the crown is pulled out.



1.1



1.2



1.3

Setting the Day

- 2.1 Pull the crown to position 3.
- 2.2 Turn the crown clockwise to advance the day hand until the desired day is set.
- 2.3 Push the crown back to position 1.



2.1



2.2



2.3

Quick change to Date

- 3.1 Set the crown to position 2.
 - 3.2 Turn the crown clockwise to set the date.
- !! Attention !! Never correct date between 10:30pm and 0:00am.



3.1



3.2



Quick change to Day

- 4.1 Set the crown to position 2.
- 4.2 Turn the crown clockwise to set the day.
- 4.3 Release the button after completing the setting.



4.1



4.2



4.3

INFO

Battery: 371 (diameter 9.5mm x 2.1mm)