


Function : Hour, Minute, Second & Date

## PRESENTATION

### Display Elements

Minute Hand  
Hour Hand  
Second Hand  
Date  
24 Hour Counter



### Control Buttons

Crown

## INSTRUCTIONS MANUAL Cal.505.24H/ 515.24H

## SETTINGS

### Setting the Time

- 1.1 Pull the crown to position 3.
- 1.2 Turn the crown to set the time.  
(remember the 24-hour cycle)
- 1.3 Push the crown back into position 1.



### Setting the Date

- 2.1 Pull the crown to position 2.  
(watch still running)
- 2.2 Turn the crown clockwise until the required date appears.
- 2.3 Turn the crown until the required date appears.
- 2.4 Push the crown back into position 1.



#### Please note:

The date can also be corrected during the day-changing phase between 10pm and midnight. The date of the following day has to be set, because no automatic date change takes place at midnight.

### Correction for 24-hour Display

- 3.1 Pull the crown to position 2.  
(watch still running)
- 3.2 Turn the crown anticlockwise until the desired time appears.
- 3.3 Push the crown back into position 1.



## INFO

Battery: 371/SR920SW