


Function : Date, Day, Month and Moon Phase

PRESENTATION

Display Elements

Minute Hand
Month
Hour Hand
Day
Second Hand
Moon Phase
Date



Control Buttons

Push Button C
Crown
Push Button A
Push Button B

INSTRUCTIONS MANUAL Cal.706.3


SETTINGS

Setting the Time

- 1.1 Pull the crown to position 2.
- 1.2 Turn the hands forward to set the time.
- 1.3 Push the crown back to position 1.

Please note:

Remember the 24-hour cycle! If you turn the hand past midnight, the moon, day and date will move forward by one day.



Setting the Moon Phase

- 2.1 Pull the crown to position 2.
- 2.2 Turn hands clockwise past midnight until the full moon position appears in the window on the dial.
- 2.4 Push the crown back to position 1.

Please note:

The date can also be corrected during the day-changing phase between 10pm and midnight. The date of the following day has to be set, because no automatic date change takes place at midnight.



Setting the Date and Day

- 3.1 Pull the crown to position 2.
- 3.2 Set movement to 6:00a.m. (outside limited time zone)
Use pusher A to set the current date and pusher B to set the current day.
- 3.3 Push the crown back to position 1.



Quick Change Corrector

- For Date: Pressing pusher A moves the date forward by one day.
- For Day: Pressing pusher B moves the day display forward by one day.
- For Month: Pressing pusher C moves the month display forward by one month.

Please note:

You must not use this quick change corrector between 11:30 p.m. and 5:30 a.m. because the automatic change mechanism is in operation between these times.